



A  x4	B  x4	C  x1	D  x1	E  x1	F  x2	G  x4	H  3mm/4mm x1	I  x1
---	---	---	--	---	---	---	---	---

EN Also required
FR Également requis
DE Ebenfalls benötigt
ES También se requiere




Pozi-drive


1




2




3




4




5




6




7



8



9



!

- A** Plastic Wall Plug (8mm Fixing Hole 40mm Long)
- B** 5mm x 50 Long Fully Threaded Pan Headed Pozi Drive Screw
- C** Safety / Security Cable
- D** M5 Flat Washer
- E** M5 10mm Button Head Hex Drive Screw / Bolt
- F** M5 x 12mm Countersunk Head Hex-drive Screw / Bolt
- G** M6 x 20mm Countersunk Head Hex-drive Screw / Bolt
- H** 3mm / 4mm Hex Key Wrench
- I** Velcro Tape

- EN** Inverted Speaker mounting
- FR** Fixation invertie de l'enceinte
- DE** Umgedrehte Lautsprechermontage
- ES** Montaje de altavoz invertido

